

#### **Step 4. Mounting the PowerUP board on the Cyberstorm MKII**

One of the adaptor pins is missing, accordingly to the MKII CPU socket, use the missing pin as a guideline to the correct direction and plug the PowerUP into the MKII.

#### **Step 5. Power Supply**

The PowerUP Board needs its own power supply. Connect one of the Amiga's Floppy power connectors to the power connector on the PowerUP. If you forget to do so, your Amiga will not boot.

#### **Step 6. Reassembly of the system.**

Insert the MkII into the A4000 according to the CyberStorm manual.  
Mount the drive bay.

#### **Step 7. Everythings done**

Your system should be operable now. Remember, we have warned you. It is not easy to extract CPUs.